

Directed Electronics Transmitter Cross Reference



Model	Part #	Date Code	Original Remote	Alternate Replacement Remote	Type
Automate Auto-key	703M	6G - 6I	499T (No Longer Available)	None	learn
Automate 1	705A	4A - 6D	None/uses fac remote	Factory OEM Remote	N/A
Automate 1	700A	6D - up	None/uses fac remote	Factory OEM Remote	N/A
Automate 2	420A	2K - 4H	493T	None	scratch
Automate 2	710A	5J - 6F	493C	493T	learn
Automate 2	710A	6G - 7D	493C	493T,484T	learn
Automate 2 HF	710A	7E - up	491T	485M, 491C	learn
Automate 3	430A	Up to 2B	465T	None	scratch
Automate 3	430A	2C - 6C	493T	None	scratch
Automate 3+	432A	5L - 7E	493C	493T,484T	learn
Automate 3+ HF	432A	7F - 8E	491T	485M, 491C	learn
Automate 4	440A	Up to 2J	465T	None	scratch
Automate 4	440A	3D - 4L	493T	None	scratch
Automate 5	435A	2E - 4F	493T	None	scratch
Automate 5+	437A	3L - 5K	493C	493T, 484T	learn
Automate 5+	437A	5L - 7E	493C	493T,484T	learn
Automate 5+ HF	437A	7F - up	491T	485M, 491C	learn
Automate 5 HF	438A	4D - 7C	491T	485M, 491C	learn
Automate 6	445A	Up to 3B	465T	None	scratch
Automate 6	445A	3E - 5A	493T	None	scratch
Automate 6 HF	448A	4I - 6H	491T	485M, 491C	learn
Automate 6 HF	448A	7C - 7G	485T (No Longer Available)	485M, 491C	learn
Automate 7	280A	All	465T	None	learn
Automate 7 HF	553A	6B - 6K	491T	485M, 491C	learn
Automate 7 HF	553A	7C - 8E	485T (No Longer Available)	485M, 491C	learn
Automate 8	281T	All	465T	None	learn
Automate 410	410A	All	471T	474A, 473A, 471C	learn
Automate 415	415A	All	None/uses fac remote	Factory OEM Remote	N/A
Automate 425	425A	8I - up	475Q (No Longer Available)	474A, 473A, 471C	learn
Automate 435	435A	8I - up	475Q (No Longer Available)	474A, 473A, 471C	learn
Automate 552	552A	All	476A (No Longer Available)	474A, 473A, 471C	learn
Automate 553	553A	6B - 8L	485T (No Longer Available)	485M, 491C	learn
Automate 553	553A	9B - up	476A (No Longer Available)	474A, 473A, 471C	learn
AM1	427A	3L - up	None/uses fac remote	474A, 473A, 471C *	learn
AM2	416A	All	474A	473A, 471C	learn
AM5	436A	3L - up	474A	473A, 471C	learn
AM6	562A	All	474A	473A, 471C	learn
AM 6.2	4101A	All	7111A		learn
AM7	563A	3H - up	474A	473A, 471C	learn
AM9	564A	All	477A, 474A	473A, 471C	learn
SSKR (All)		All	Not included in kit	471A, 471C	learn
BOA 105B	105B	All	474B	None	learn
BOA 165B	165B	All	474B	None	learn
BOA 175B	175B	All	475B	None	learn
BOA 265B	265B	All	474B	None	learn
BOA 275B	275B	All	475B	None	learn
BOA 500	500B	All	473B	None	learn
Equalizer 1	723E	6E	493T	None	scratch
Equalizer 1	725B	All	491T	485M, 491C	learn
Equalizer 2	432E	6A	493C	493T, 484T	learn
Equalizer 3	437E	5H	493C	493T, 484T	learn
Failsafe 3	703T	6G - 6I	499T (No Longer Available)	None	learn

Hornet 121T	121T	4C - 6J	493T	None	scratch
Merlin 2000	122T	All	470T	471C	learn
Merlin 3000	225T	All	482T,473B	None	learn
Hornet 553T	553T	7H - 8B	491T	485M, 491C	learn
Hornet 553T	555T	9B - up	475Q (No Longer Available)	474T, 473T, 471C	learn
Hornet 554T	554T	All	477T, 474T	473T, 471C	learn
Hornet 560T	560T	All	479H		
Hornet 569T	569T	All	471H	471H, 471C	learn
Hornet 570T	570T	All	471T	471C	learn
Hornet 563T	563T	All	474T	473T, 471C	learn
Hornet 564T	564T	All	477T, 474T	473T, 471C	learn
Hornet 700T	700T	6A - up	None/uses fac remote	Factory OEM remote	N/A
Hornet 705T	705T	4G - 6A	None/uses fac remote	Factory OEM remote	N/A
Hornet 706T	706T	4A	No remote/ NOT RF	N/A	N/A
Hornet 707T	707T	2F - 4A	No remote/ NOT RF	N/A	N/A
Hornet 710T	710T	Up to 7J	465T	None	scratch
Hornet 710T	415T	8A - up	471T	474T, 473T, 471C	learn
Hornet 715T	715T	All	465T	None	scratch
Hornet 717T	717T	2G - 3D	465T	None	scratch
Hornet 718T	718T	2E - 4A	NLA	None	N/A
Hornet 718T	718T	4F - 6D	493T	None	learn
Hornet 718T	718T	6G - 7B	493C	493T	learn
Hornet 719T	719T	2C - 3B	NLA	None	N/A
Hornet 719T	719T	3D - 6D	493T	None	scratch
Hornet 719T	719T	6F - 7C	492T	493T	learn
Hornet 719T	719T	7D - 7J	491T	485M, 491C	learn
Hornet 720T	720T	2C - 3C	NLA	None	N/A
Hornet 720T	720T	3E - 6A	493T	None	scratch
Hornet 720T	720T	7J - up	491T	485M, 491C	learn
Hornet 721T	721T	2J - 2L	No Longer Available	493T	scratch
Hornet 721T	721T	2J - 5E	493T	None	scratch
Hornet 722T	722T	2H - 4G	493T	None	scratch
Hornet 723T	723T	5G - 7E	493T	None	scratch
Hornet 725T	725T	7G - up	491T	485M, 491C	learn
Hornet 727T	727T	All	No remote/ NOT RF	474T, 473T, 471C *	N/A
Hornet 730T	730T	2E - 3K	465T	None	scratch
Hornet 730T	730T	3K-1 - 7A	493T	None	scratch
Hornet 730T	730T	7G - up	491T	485M, 491C	learn
Hornet 732T	732T	6C - 7E	493C	484T	learn
Hornet 732T	732T	7J - 8E	491T	485M, 491C	learn
Hornet 735T	735T	4C - 4G	493T	None	scratch
Hornet 737T	737T	4I - 5J	493C	493T, 484T	learn
Hornet 740T	281T	All	465T	None	learn
Hornet 740T	740T	4K - up	473T	474T, 471C	learn
Hornet 742T	742T	All	474T	473T, 471C	learn
Hornet 745T	745T	All	477T, 474T	473T, 471C	learn
Hornet 748T	748T	8L - 9A	491T	485M, 491C	learn
Hornet 755T	755T	2B - 4G	465T	None	scratch
Hornet 851T	851T	All	471T	471C	learn
Pro Guard 2300	723G	6D - 6F	493T	None	scratch
Pro Guard 2500	725G	ALL	491T	485M, 491C	learn
Pro Guard 4700	437B	5B - 5G	493C	493T, 484T	learn
Pro Guard 4800	438B	5B - 5H	493C	493T, 484T	learn
Pro Guard 7100	271B	2L - 5A	493C	493T, 484T	learn
Python 55	723B	6J - 7E	493T	None	scratch
Python 60	261S	2K - 4H	493T	None	scratch
Python 60	430P	4I - 6H	493T	None	scratch
Python 70	271S	2L - 5C	484T	493C, 493T	learn
Python 80	281S	2L - 5C	484T	493C, 493T	learn
Python 90	291S	2K - 4L	484T	None	learn
Python 400 HF	410P	8G - up	471T	474P, 473P, 471C, 7141P	learn
Python 440 HP	416P	All	474P	473P, 471C, 7141P	learn
Python 450 HF	552P	7H - up	491T	485M, 491C	learn
Python 460 HP	426P	All	473P	474P, 471C, 7141P	learn
Python 500	3101P	All	474P	473P, 471C, 7141P	learn

Python 502	3102P	All	7141P	474P, 473P, 471C	learn
Python 571XP	572P	4G - 4K	487P	474P, 473P, 471C	learn
Python 571XP	572P	5J - up	488P	474P, 473P, 471C	learn
Python 581 XP	542P	All	479P	472P	learn
Python PC 650 HF(ESP)	429P	9A - up	471T	474P, 473P, 471C, 7141P	learn
Python 650 ESP	429P	All	471t	474P, 473P, 471C, 7141P	learn
Python 625 HF	430P	8D - up	471T	474P, 473P, 471C, 7141P	learn
Python 650	432P	5L - 7E	493C	493T, 484T	learn
Python 650 HF	432P	7F - 8B	491T	485M, 491C	learn
Python 650 HF	432P	8B - up	471T	474P, 473P, 471C, 7141P	learn
Python 660 HP	436P	All	474P	473P, 471C, 7141P	learn
Python 671 XP	437P	All	487P	474P, 473P, 471C, 7141P	learn
Python 680 XP	434P	All	479P	472P	learn
Python 700	3201P	All	488P, 474P	473P, 471C, 7141P	learn
Python 702	3202P	All	488P, 7141P	474P, 473P, 471C	learn
Python 750	437P	5B - 5K	493C	493T, 484T	learn
Python 750	437P	5L - 7C	493C	493T, 484T	learn
Python 871 XP	567P	4E - 4I	487P	474P, 473P, 471C	learn
Python 871XP	567P	5E - up	488P	474P, 473P, 471C	learn
Python 872	5202	All	7251P, 7152P		learn
Python 880 XP	554P	All	478P (No Longer Available)	479P, 472P	learn
Python 881 XP	564P	All	479P	472P	learn
Python 900	3301P	All	489P, 474P	487P, 473P, 471C, 7141P	learn
Python 902	3302P	All	489P, 7141P	474P, 473P, 471C	learn
Python 950	4301P	All	7701P	7701P, 7642P	learn
Python 990	5301P	All	7701P	7701P, 7642P	learn
Python 1000 HF	268S	4F-4H	491T	485M, 491C	learn
Python 1000 HF	438P	4G - 8B (a)	491T	485M, 491C	learn
Python 1000 HF	438P	8B - up	471T	474P, 473P, 471C, 7141P	learn
Python PC 1000 HF(ESP)	439P	7J - up	475T (No Longer Available)	474P, 473P, 471C, 7141P	learn
Python 1000 ESP	439P	All	475Q (No Longer Available)	474P, 473P, 471C, 7141P	learn
Python 1090	5501P	All	7541P	7141P, 474P, 473P, 471C	learn
Python 1200 HP	561P	All	473P	474P, 471C, 7141P	learn
Python 1400XP	562P	All	474P	473P, 471C, 7141P	learn
Python 1400 XPL	562PL	All	7641P	7641P	learn
Python 1500 HF	553P	5J - 7C	491T	485M, 491C	learn
Python 1500 HF	553P	7C - 7L	485T (No Longer Available)	485M, 491C	learn
Python 1500 HF	553P	8D - 8I	475T (No Longer Available)	474P, 473P, 471C, 7141P	learn
Python 1500 HF(ESP)	553P	9B - up	475Q (No Longer Available)	474P, 473P, 471C, 7141P	learn
Python 1600 XP	563P	All	474P	473P, 471C, 7141P	learn
Python 2000 HF	371P	6A - 6F	485T (No Longer Available)	485M, 491C	learn
Python 3000 HF	381P	5H - 6H	485T (No Longer Available)	485M, 491C	learn
Python 3000 HF	381P	6I - 7E	485T (No Longer Available)	485M, 491C	learn
Python 3000 HF	381P	7F - 7L	485T (No Longer Available)	485M, 491C	learn
Python PC 3000 HF	381P	8B - 8G	475T (No Longer Available)	474P, 473P, 471C, 7141P	learn
Python PC 3000 HF(ESP)	381P	9A - up	475Q (No Longer Available)	474P, 473P, 471C, 7141P	learn
Python 3000 ESP	381P	All	475T (No Longer Available)	474P, 473P, 471C, 7141P	learn
Rattler 110D	312R	All	473R	473T, 471C	learn

Rattler 210D	322R	All	473R	473T, 471C	learn
Rattler 310D	332R	All	473R	473T, 471C	learn
Rattler 359D	359R	All	471T	473T, 471C	learn
Rattler 369D	369R	All	473R	473T, 471C	learn
Sidewinder 1000	718B	3K	No Longer Available	None	N/A
Sidewinder 2000	719B	3K	493T	None	scratch
Sidewinder 2200	721B	3K - 5F	493T	None	scratch
Sidewinder 3000	720B	3K - 4H	493T	None	scratch
Sidewinder 3000 HF	410S	8G - up	471T	474T, 473T, 471C	learn
Sidewinder 3200	722B	3K	493T	None	scratch
Sidewinder 3200 HS	416S	All	474S (No Longer Available)	474T, 473T, 471C	learn
Sidewinder 3300 HS	426S	All	473S (No Longer Available)	474T, 473T, 471C	learn
Sidewinder 3500	552S	7H - up	491T	485M	learn
Sidewinder 4200	420B	2K - 5F	493T	None	scratch
Sidewinder 4200	420S	5B - 5F	493T	None	scratch
Sidewinder 4500 HF	430S	8D - up	471T	474T, 473T, 471C	learn
Sidewinder 5000	432S	5L - 7E	493C	493T, 484T	learn
Sidewinder 5000 HF	432S	7F - 8B	491T	485M, 491C	learn
Sidewinder 5000 HF	432S	8B - up	471T	474T, 473T, 471C	learn
Sidewinder 5000 HF(ESP)	429S	9A - up	471T	474T, 473T, 471C	learn
Sidewinder 5000 ESP	429S	All	471T	474T, 473T, 471C	learn
Sidewinder 5200	430S	2H - 4E	493T	None	scratch
Sidewinder 5200 XS	436S	All	474S (No Longer Available)	474T, 473T, 471C	learn
Sidewinder 6000	435B	2L - 4F	493T	None	scratch
Sidewinder 6000	437S	4J - 6H	493C	493T, 484T	learn
Sidewinder 6000	437S	6I - 7E	493C	493T, 484T	learn
Sidewinder 6000 HF(2 btn)	437S	7F - 7I	491T	485M, 491C	learn
Sidewinder 6000 HF	438S	4J - 8B (a)	491T	485M, 491C	learn
Sidewinder 6000 HF	438S	8D - up	471T	474T, 473T, 471C	learn
Sidewinder PC 6000 HF	439S	8B - up	475T (No Longer Available)	474T, 473T, 471C	learn
Sidewinder 6000 ESP	439S	All	475Q (No Longer Available)	474T, 473T, 471C	learn
Sidewinder 6100	440B	2L - 3D	493T	None	scratch
Sidewinder 6200	445B	2L - 4H	493T	None	scratch
Sidewinder 6500 HF	553S	5K - 6H	491T	485M, 491C	learn
Sidewinder 6500 HF	553S	7A - 8B	485T (No Longer Available)	485M, 491C	learn
Sidewinder 6500 HF	553S	8D - 8I	475T (No Longer Available)	474T, 473T, 471C	learn
Sidewinder 6500 HF(ESP)	553S	9B - up	475Q (No Longer Available)	474T, 473T, 471C	learn
Sidewinder 7000 HF	381S	5H - 6H	485T (No Longer Available)	485M, 491C	learn
Sidewinder 7000 HF	381S	6I - 7C	485T (No Longer Available)	485M, 491C	learn
Sidewinder 7000 HF	381S	7D - 7H	485T (No Longer Available)	485M, 491C	learn
Sidewinder 7000 ESP	381S	All	475T (No Longer Available)	474T, 473T, 471C	learn
Sidewinder PC 7000 SHF	381S	TBA	475Q (No Longer Available)	474T, 473T, 471C	learn
Sidewinder 7100	271B	2L - 5A	484T	493C, 493T	learn
Sidewinder 7200	281B	All	484T	493C, 493T	learn
Steal Stopper 50	220S	All	465T	None	scratch
Steal Stopper 50/S	221S	All	465T	None	scratch
Steal Stopper 60	225S	Up to 2E	465T	None	scratch
Steal Stopper 60	261S	2E - 2I	493T	None	scratch
Steal Stopper 60/S	226S	All	465T	None	scratch
Steal Stopper 70	271S	Up to 2E	465T	None	learn
Steal Stopper 70	271S	2F - 2J	493T	484T	learn
Steal Stopper 80	281S	EZS4CXDEI235	465T	None	learn
Steal Stopper 80	281S	EZSDEI280	493T	484T	learn
Steal Stopper 90	291S	2E - 2J	484T	None	learn
Steal Stopper 1000	SS1000	All	465T	None	scratch
Steal Stopper 2000	SS2000	All	No remote/NOT RF	None	N/A
Steal Stopper PRO 3000	SS3000	All	No remote/NOT RF	None	N/A
Steal Stopper PRO 4000	SS4000	All	No remote/NOT RF	None	N/A
Steal Stopper PRO 5000	SS5000	All	465T (optional)	None	scratch
Steal Stopper 6001	SS6001	All	No remote/NOT RF	None	N/A
Stinger W/515R	438K	8K	471T	474S, 473S, 471C	learn
Stinger Keyless entry	711K	8K	471T	474S, 473S, 471C	learn
Stinger W/514T	438J	8K	471T	474S, 473S, 471C	learn

Wasp	718W	3F - 3H	NLA	None	N/A
Wasp	718W	4/95 - 5/95	NLA	None	N/A
Wasp	718W	6/95 - 10/95	465T	None	learn
Wasp	718W	6F - 7C	493C	None	learn
Wasp	718W	7D - up	491T	485M, 491C	learn
Valet 450T	450T	6D - up	No remote/ NOT RF	N/A	N/A
Valet 450R	450R	6D - 6I	485T (No Longer Available)	485M	learn
Valet 450R	450R	8C - 8E	475T (No Longer Available)	474T,473T, 485M	learn
Valet 519T	519T	2J - 5J	465T / 493C	493T, 484T	learn
Valet 519T	519T	6A - up	493C	493T, 484T	learn
Valet 519H	519H	5A - 8H	491T	485M, 491C	learn
Valet 519H	519H	8K - up	471T	474T, 473T, 471C	learn
Valet 550T	550T	All	No remote/ NOT RF	N/A	N/A
Valet 551R	551R	7G - 9A	491T	485M, 491C	learn
Valet 551R	551R	9B - up	471T	471C, 473T	learn
Valet 551T	551T	All	No remote/ NOT RF	N/A	N/A
Valet 552T	552T	4I - up	491T	485M, 491C	learn
Valet 554T	554T	All	477T, 474T	473T, 471C	learn
Valet 561T	561T	All	No remote/ NOT RF	473Tw/receiver upgrade	learn
Valet 561R	561R	All	473T	473T, 471C	learn
Valet 562T	562T	All	474T	473T, 471C	learn
Valet 563T	563T	All	474T	473T, 471C	learn
Valet 710T	710A	5J - 6F	493C	493T, 484T	learn
Valet 710T	710T	6G - 7D	492C	493T, 484T	learn
Valet 710T	710T	7E - up	491T	485M, 491C	learn
Valet 711T	711T	2C - 5K	465T	None	scratch
Valet 711T	711T	7E - up	491T	485M, 491C	learn
Valet 712T	712T	2J - 7D	465T	None	scratch
Valet 712T	712T	4K - up	474T	473T, 471C	learn
Viper 50	405V	All	No remote/NOT RF	None	N/A
Viper 100	410V	All	465T	None	scratch
Viper 100 HF (ESP)	410V	8G - up	471T	474V, 473V, 471C, 7141V	learn
Viper 130 HV	561V	All	473V	474V, 473V, 471C, 7141V	learn
Viper 150	715V	All	465T	None	scratch
Viper 150 HF	552V	7H - 8L	491T	485M	learn
Viper 150 ESP	552V	9C - up	471T	474V, 473V, 471C, 7141V	learn
Viper 160 XV	562V	All	474V	474V, 473V, 471C, 7141V	learn
Viper 160 XVL	562VL	All	7641V	7641V	learn
Viper 200	420V	Up to 2B	465T	None	scratch
Viper 200	420V	2C - 5J	493T	None	scratch
Viper 200	122V	0D - up	470T	471C	learn
Viper 201	201V	All	465T	None	scratch
Viper 210 HV	416V	All	474V	474V, 473V, 471C, 7141V	learn
Viper 211	412V	All	474V	474V, 473V, 471C, 7141V	learn
Viper C 30	430C	2D - 5B	493T	None	scratch
Viper 300	430V	Up to 2B	465T	None	scratch
Viper 300	430V	2C - 7E	493T	None	scratch
Viper 300 HF	430V	7G - 8B (a)	491T	485M, 491C	learn
Viper 300 HF	430V	8B - 9A	471T	474V, 473V, 471C, 7141V	learn
Viper PC 300 HF (ESP)	429V	All	471T	474V, 473V, 471C, 7141V	learn
Viper 300+	432V	5L - 7E	493C	493T,484T	learn
Viper 300+	432V	7F - 8B (a)	491T	485M, 491C	learn
Viper 300+ HF	432V	8B - 9B	471T	474V, 473V, 471C, 7141V	learn
Viper 300 ESP	429V	All	471T	474V, 473V, 471C, 7141V	learn
Viper 330V	427V	All	No remote/NOT RF	474V, 473V, 471C *, 7141V	N/A
Viper 350 Classic	330V	Up to 2A	465T	None	scratch
Viper 350 Classic	330V	2B - 4E	493T	None	scratch
Viper 350 HV	426V	All	473V	474V, 471C, 7141V	learn
Viper 400	440V	Up to 2C	465T	None	scratch
Viper 400	440V	2D - 4L	493T	None	scratch
Viper 450 Classic	340V	Up to 2G	465T	None	scratch
Viper 450 Classic	340V	2H - 4B	493T	None	scratch
Viper 500	435V	Up to 2D	465T	None	scratch
Viper 500	435V	2E - 4C	493T	None	scratch
Viper C 50	437C	4C - 5K	493C	493T, 484T	learn

Viper C 50	437C	5L - 6C	493C	493T,484T	learn
Viper 500+	437V	3L - 5K	493C	493T, 484T	learn
Viper 500+	437V	5L - 7E	493C	493T,484T	learn
Viper 500 HF(Code Plus)	438V	4D - 7L	491T	485M, 491C	learn
Viper 500 HF	438V	8B - up	471T	474V, 473V, 471C, 7141V	learn
Viper PC 500 HF (ESP)	439V	7J - up	475T	474V, 473V, 471C, 7141V	learn
Viper 500 ESP	439V	All	475Q (No Longer Available)	474V, 473V, 471C, 7141V	learn
Viper 500 NX	436V	5G	492T	None	learn
Viper 550 Classic	335V	Up to 2C	465T	None	scratch
Viper 550 Classic	335V	2D - 4B	493T	None	scratch
Viper 550 HF	553V	5I - 6J	491T	485M, 491C	learn
Viper 550 HF	553V	7D - 8B	485T (No Longer Available)	485M, 491C	learn
Viper 550 HF	553V	8D - 9A	475T (No Longer Available)	474V, 473V, 471C, 7141V	learn
Viper 550 HF (ESP)	553V	9B - up	475Q (No Longer Available)	474V, 473V, 471C, 7141V	learn
Viper 560 XV	563V	All	474V	474V, 473V, 471C, 7141V	learn
Viper 571 XV	572V	4G - 4J	487V	474V, 473V, 471C, 7141V	learn
Viper 571XV	572V	5E - up	488V	474V, 473V, 471C, 7141V	learn
Viper 591 XV	542V	All	479V	472V	learn
Viper C 60	445C	2D - 4L	493T	None	scratch
Viper 600	445V	Up to 2B	465T	None	scratch
Viper 600	445V	2C - 5E	493T	None	scratch
Viper 600 Classic	345V	Up to 2A	465T	None	scratch
Viper 600 Classic	345V	2C - 4B	493T	None	scratch
Viper 600 HF (Code Plus)	448V	4L - 6L	491T	485M, 491C	learn
Viper 600 HF (Code Plus)	448V	7A - 8B (a)	485T (No Longer Available)	485M, 491C	learn
Viper 600 HF	448V	8B - 8L	475T (No Longer Available)	474V, 473V, 471C, 7141V	learn
Viper PC 600HF (ESP)	449V	9A - up	475Q (No Longer Available)	474V, 473V, 471C, 7141V	learn
Viper 600 ESP	449V	All	475Q (No Longer Available)	474V, 473V, 471C, 7141V	
Viper 650 XV	436V	All	474V	473V, 471C, 7141V	learn
Viper 671 XV	437V	All	487V	474V, 473V, 471C, 7141V	learn
Viper 690 XV	434V	All	479V	479V, 472V	learn
Viper C 70 HF	448C	5E - 6D	491T	485M	learn
Viper Ultra 700	370V	Up to 2H	493T	493C, 484T	learn
Viper Ultra 700	370V	2I - 5C	484T	493C,493T	learn
Viper 700 HF	371V	6A - 6F	485T (No Longer Available)	485M, 491C	learn
Viper 700 ESP	379V	0E - 5D	476V	474V, 473V, 471C, 7141V	learn
Viper 771 XV	567V	4E - 4L	487V	474V, 473V, 471C, 7141V	learn
Viper 771 XV	567V	5E - up	488V	474V, 473V, 471C, 7141V	learn
Viper 790 XV	554V	All	478V (No Longer Available)	479V, 472V	learn
Viper 791 XV	564V	All	479V	472V	learn
Viper Ultra 800	380V	Up to 2D	493T	493C, 484T	learn
Viper Ultra 800	380V	2D - 5A	484T	493C, 493T	learn
Viper 800 HF	381V	5H - 6H	485T (No Longer Available)	485M, 491C	learn
Viper 800 HF	381V	6I - 7B	485T (No Longer Available)	485M, 491C	learn
Viper 800 HF	381V	7C - 7L	485T (No Longer Available)	485M, 491C	learn
Viper PC 800 SHF	381V	8B - 8F	475T (No Longer Available)	474V, 473V, 471C, 7141V	learn
Viper 800 SHF ESP	381V	8G - UP	475T (No Longer Available)	474V, 473V, 471C, 7141V	learn
Viper 800 ESP	381V	All	475T	474V, 473V, 471C, 7141V	learn
Viper 850XV	446V	All	474V	473V, 471C, 7141V	learn
Viper Ultra 900	390V	Up to 4L	484T	None	learn
Viper 1000	3101V	All	474V	473V, 471C, 7141V	learn
Viper 1002	3102V	All	7141V	474V, 473V, 471C	learn
Viper 3000	3201V	All	488V, 474V	473V, 471C, 7141V	learn
Viper 3002	3202V	All	488V, 7141V	474V, 473V, 471C	learn
Viper 5000	3301V	All	489V, 474V	473V, 471C	learn
Viper 5002	3302V	All	489V, 7141V	474V, 473V, 471C	learn
Viper 5500	4301V	All	7701V	7701V, 7642V	learn
Viper 5701	5202V	All	7251V, 7152V		learn
Viper 5900	5301V	All	7701V	7701V, 7642V	learn
Viper 7900	5501V	All	7541V	7141V, 474V, 473V, 471C	learn
* can use remotes when adding a receiver and antenna cable					
				Last Updated 02-29-08	